



**NOTES:**

1. INSTALL SPRINKLER HEADS 12" FROM FENCES WALLS OR BUILDINGS. DO NOT INSTALL SPRINKLER HEAD WITHIN 10 FT OF PAVING, CURBS OR TURF EDGES.
2. INSTALL SPRINKLER HEADS PLUMB. ADJUST SPRAY TO COVER LANDSCAPE AREA WITHOUT OVERSPRAY ONTO PAVING, FENCES, WALLS OR BUILDINGS.
3. ALL THREADED CONNECTIONS TO HAVE TEFLON TAPE OR PASTE.



CITY OF BREA

**SPRAY HEAD ON RISER**

APPROVED:

*Rex Sij*  
CITY ENGINEER

DATE: 10-15-2013

STD. PLAN NUMBER

604-0

SHEET 1 OF 1