



- ① SPREAD ON WALL AND SECURE WITH 'TUMAX PLANT ANCHOR' VINE TIES ATTACHED TO WALL WITH CLEAR SILICONE GLUE. DO NOT USE WIRE OR METAL TO TIE VINES. USE WHITE, BLACK OR GREEN VINYL ATTACHMENTS TO CONNECT VINES TO WALL TIES.
- ② REMOVE NURSERY STAKE.
- ③ 2" MULCH LAYER, MAINTAIN CONSTANTLY. SEE SPECIFICATIONS UNLESS OTHERWISE INDICATED ON PLAN.
- ④ ADJACENT MATERIAL, SEE PLAN.
- ⑤ PLANTING TABLETS.
- ⑥ COMPACTED BACKFILL, SEE SPECS.
- ⑦ SCARIFY SIDES AND BOTTOM OF PLANTING PIT.
- ⑧ TOP OF ROOTBALL TO BE 1/2" BELOW FINISH SURFACE.
- ⑨ UNDISTURBED EXISTING SOIL TO FORM PEDESTAL. REPLACE W/ COMPACTED SOIL IF HARDPAN EXISTS.



## VINE PLANTING

APPROVED:

*[Signature]*  
CITY ENGINEER

DATE: 10-15-2013

STD. PLAN NUMBER

609-0

SHEET 1 OF 1